
# KV-2585AS

# SERVICE MANUAL

### Australian Model

Chassis No. SCC-D23L-A



**GP-1A** CHASSIS

MODELS OF THE SAME SERIES		
KV-2585AS		
KV-2584AS		
KV-2566AS/2966AS		

#### **SPECIFICATIONS**

Power requirements Power consumption

Color system

Television system

Channel coverage

110 - 240 V AC, 50/60 Hz

140 W

PAL, PAL 60, NTSC4.43.

NTSC3.58

B/G

VHF UHF 0 - 11, 5A28 - 69

**CATV** 

S01 - S03

S1 - S20

**Audio output** 

Inputs

**Outputs** 

5 W

Antenna: 75 ohms

VIDEO IN jacks: phono jacks

Video: 1 Vp-p, 75 ohms

Audio: 500 mVrms, high impedance

MONITOR OUT jacks:

phono jacks

Video: 1 Vp-p, 75 ohms Audio: 500 mVrms, low

impedance

Picture tube

**Dimensions** 

Mass

Approx. 64 cm (25 inches)  $595 \times 528 \times 470 \text{ mm (w/h/d)}$ 

35 kg

Design and specifications are subject to change without notice.




TRINITRON® COLOUR TV SONY

## SECTION 1 GENERAL

#### **Operating Instructions**


Before operating the TV, please read this manual thoroughly and retain it for future reference.

#### 1-1. ANTENNA CONNECTION




The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remein as in the manual.


#### 1-2. CONNECTING A VTR




#### 1-3. PRESETTING TV CHANNELS




#### 1-4. WATCHING THE TV




#### 1-6. ADJUSTING THE PICTURE





#### 1-7. USING CONVENIENT FEATURES



#### 1-8. TROUBLESHOOTING


If you have any problem, check the countermeasure for each symptom listed below. If the problem still cannot be solved, contact your nearest service facility.

Sym	ptom	Countermeasure
Snowy picture Noise (sound interference)	以	Check the antenna position.     Check antenna/cable connections on the TV or wall.     Fine-tune the channel manually.
Dotted lines or stripes	HEYER AND AND A	This is often caused by local interference (for example, cars neon signs, hairdryers etc.). Adjust the antenna for minimur interference.
Double images or "ghosts"	黨.	Reflections from nearby mountains or buildings often cause this problem. Connecting a highly directional outdoor antenna may improve the picture.
No picture No sound		Check the power cord connection. Make sure POWER is switched on. Check the antenna connection. Check the VTR connections.
Good picture No sound	X	Press VOLUME +. Press MUTE. Check the VTR connections.
No color Abnormal color		Check the COLOR SYSTEM setting. Adjust the color intensity. This is often caused by incomplete tuning. Try presetting directly.
Poor or no picture, good sound		Adjust brightness, color intensity or picture contrast.     Press NORMAL.     Check VTR connections.


### SECTION 2 DISASSEMBLY

#### 2-1. K BOARD REMOVAL

Note: Follow the disassembly procedure in the numerical over given.




#### 2-2. SERVICE POSITION FOR A BOARD



#### 2-3. PICTURE TUBE REMOVAL


Note: Follow the disassembly procedure in the numerical over given.




#### REMOVAL OF ANODE-CAP

NOTE: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT chield or carbon painted on the CRT, after removing the anode.

#### REMOVING PROCEDURES




- the direction indicated by the arrow @.
- 1) Turn up one side of the rubber cap in 2 Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow (b).




When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ©.

#### HOW TO HANDLE AN ANODE-CAP

- Don't hurt the surface of anode-caps with sharp shaped material!
- Don't press the rubber hardly not to hurt inside of anode-caps! A material fitting called as shatter-hook terminal is built in the rubber.
- Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.





### SECTION 3 SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

The control and switch below should be set as follows unless otherwise noted:

PICTURE control----- normal

BRIGHTNESS control ..... normal

Perform the adjustments in order as follows:

#### Preparation

- Feed in the white pattern signal.
- Before starting degauss the entire screen.

#### 3-1. BEAM LANDING

- 1. Input a raster signal with the pattern generator.
- 2. Loosen the deflection yoke mounting screw, and set the purity control to the center as shown in Fig. 2.
- 3. Turn the raster signal of the pattern generator to green.
- 4. Move the deflection yoke backward and adjust with the purity control so that green is in the center and red and blue are at the sides evenly. (Fig.3)
- 5. Move the deflection yoke forward and adjust so that the entire screen becomes green. (Fig.1)
- 6. Switch over the raster signal to red and blue and confirm the condition.
- 7. When the position of the deflection yoke is determined, tighten it with the deflection yoke mounting screw.
- 8. When landing at the corner is not right, adjust by using the disk magnets. (Fig.4)






Fig. 1

- 1. Beam Landing
- 2. Convergence
- 3. Focus
- 4. White Balance

Note: Test Equipment Required.

- 1. Color-bar Pattern Generator
- 2. Degausser
- 3. Digital multimeter









Fig. 4


#### 3-2. CONVERGENCE

Preparation


- Before starting perform FOCUS, H.SIZE, V.LIN and V.SIZE adjustments.
- Set BRIGHTNESS control to minimum.
- Feed in dot pattern.
- (1) Horizontal and Vertical Static Convergence




- 1. Adjust H.STAT VR to converge red, green and blue dots in the center of the screen. (Horizontal movement)
- 2. Adjust V.STAT magnet to converge red, green and blue dots in the center of the screen. (Vertical movement)
- 3. If the red, green and blue dots do not coverge in the center of the screen with H.STAT VR, perform horizontal convergence adjustment using H.STAT VR and V.STAT magnet as shown below.(In this case, H.STAT VR and V.STAT magnet effect each other.)



 Tilt the V.STAT magnet and adjust static convergence to open or close the V.STAT magnet.




4. When the V.STAT magnet is moved in the direction of arrow (a) and (b) , red, green and blue dots move as shown below.




If the blue dot do not Converge with red and green dots, perform following steps.

● HMC and VMC correction for BMC (Hexapole) Magnet.

 HMC (Horizontal Miss Convergence) correction and motion of the Electron Beam with the BMC Magnet.




2. VMC (Vertical Miss Convergence) correction and motion of the Electron Beem with the BMC Magnet.




- (2) Dynamic Convergence Adjustment Preparation
- Before starting perform Horizontal and Vertical static convergence Adjustmet.
- 1. Slightly loosen deflection yoke screw.
- 2. Remove deflection yoke spacers.

- 3. Move the deflection yoke for best convergence as shown below.
- 4. Tighten the deflection yoke screw.
- 5. Install the deflection yoke spacers.



 ${\bf (3)\ Screen\ -corner\ Convergence}$ 



#### **3-3. FOCUS**


Adjust FOCUS control for best picture.

### 3-4. SCREEN(G 2) and WHITE BALANCE [SCREEN(G2)]

- 1. Input dots patteren.
- 2. Set the PIC control at minimum and set the BRT control at maximum.
- 3. Confirm the BKG voltage is less than 180 Vdc when turning RV 706 (R.BKG), RV 704 (G.BKG) and RV 702 (B.BKG).
- 4. Note the color when becomes visible first when turning RV 708 (SCRN).


#### [WHITE BALANCE(Cut off)]

- 1. Input collor bar signl.
- 2. Set the PIC control to minimum and set the BRT control at normal.
- 3. Turn RV 703 (B.DRIVE) and RV 705 (G.DRIVE) fully clockwise.
- 4. Set RV 706 (R.BKG), RV 704 (G.BKG) and RV 702 (B.BKG) to minimum.
- 5. Turn RV 707 (SUB BRT) slowly to obtain a faintly visible blue stripe.
- 6. Switch over all white signal.
- 7. Adjust BKG controls for best white balance.
- 8. Set the PICTURE control to maximum. Observe the screen and adjust the DRIVE controls for best white balance.
- 9. Repeat steps 7 and 8.



### SECTION 4 CIRCUIT ADJUSTMENTS

#### 4-1. A BOARD ADJUSTMENTS




#### RF AGC ADJUSTMENT (IF201)

- 1. Receive a strong off-air signals.
- 2. Adjust RF AGC VR control so that snow noise and cross-modulation just disappear from the picture.

#### Channel display POSITION ADJUSTMENT (RV001)

- 1. Set PIC control to maximum.
- 2. Adjust RV001 so that the channel display should be positioned at up-right on the screen.



#### A · P · C ADJUSTMENT (CV443) (PAL)

- 1. Input the PAL color-bar signal.
- 2. Set the PIC, COL, and BRT controls to normal.
- 3. Short circuit between pin ② and pin ③ of IC301 with jumper.
- 4. Adjust CV443 for suitable color intensity.
- 5. Remove a jumper.

### REF OSC 3.58 ADJUSTMENT (CV358) (NTSC 3.58)


- Short circuit between pin and pin of IC301 with a jumper.
- 2. Set the PIC, COL and BRT controls to normal.
- 3. Input NTSC 3.58 color-bar signal.
- 4. Adjust CV358 for suitable color intensity.
- 5. Remove the jumper.

### ANTI PAL, LINE CRAWLING ADJUSTMENT (RV301,RV302,T301)


#### • ANTI PAL ADJUSTMENT

- 1. Input PAL color-bar signal.
- 2. Set the PIC, COL and BRT controls to normal.
- 3. Connect the oscilloscope to pin ③ of CN302 connector.
- 4. Adjust RV301 (DELAY) and RV302 (PHASE) to obtain the waveform as shown below.


#### • LINE CRAWLING ADJUSTMENT




- 1. Input the PAL color-bar signal.
- 2. Set the PIC, COL and BRT controls to normal.
- 3. Connect the oscilloscope to pin ③ of CN302 connector.
- 4. Adjust T301 for minimum line crawling.




#### **RV822 PIN ANP (PINCUSHION AMPLIFIER)**




#### **RV823 PIN PHASE (PINCUSHION PHASE)**




#### **RV821 PIN COR (PINCUSHION CORRECT)**




#### **RV825 C.CORR (CORNER CORRECT)**




#### **RV824 H.SIZE (HORIZONTAL SIZE)**




#### **RV503 V.SIZE (VERTICAL SIZE)**



#### **RV502 V.LIN (VERTICAL LINEARITY)**




#### **CN550 H.CENT (HORIZONTAL CENTER)**





#### **RV551 V.CENT (VERTICAL CENTER)**



#### 5-2. CIRCUIT BOARDS LOCATION







#### K BOARD WAVEFORMS

1.0Vp-p (H)	2 1.0Vp-p (H)	3 2.0Vp-p (H)
(4)	5 PAL/NTSC	9 (P)
2.0Vp-p (H )  7PAL/NTSC	0.6Vp-p(H)	1.5Vp-p(H)
1.0Vp-p (H )		

#### 5-4. SEMICONDUCTORS

**CXA1213S** 



CXK5864BSP-10L MC14066BCP MC33079P SAA5231-A6



KEY-C00SV-F



LA7016



LM393P RC4558P ST24C02AB1 TEA2031A



LM1036N



L78LR05D-MA



MC14052BCP MC14049UBCP TDA8444 μ PD4053BC



PCA84C840P/054 TC6011N

(Top view)

RC78L09A

**RC7812FA** 

SAA5243P/E/M3

(Top view)

STR-S5741

0

TA8662N



**TDA2007** 



**TD6710AN** 



µ PC1498H



µ PC574J



µ РС7893HF



DTA114ES DTC114ES DTC124ES DTC143TS DTC144ES 2SC3327-A



2SA1175-HFE 2SC2785-HFE 2SC3311A




2SA1220A-P 2SC2611 2SC2688-LK



2SA1221-L 2SB734-34 2SC2958-L 2SD774-34




2SA1306A-Y 2SC3298B-Y



2SC2216



2SC4927-01



2SD1408-Y



2SD1761



2SK669



D4SB60L-F






#### D5LC20U



#### MC932



# EGP30GL-6072 ERC06-15S RU-1P RU-3AM





### ERD29-08J RU4DS





EU2Z ES1F-N R2K WG713A



RD10SB1



MC911







#### **SEL1222R-C**







#### 6-1. CHASSIS

● : BVTP3×12 7-685-648-79 ■: BVTP4×16 7-685-663-79 **(16)** (15) **(14)** BVTP3×16 7-685-650-79 **\_**9 18 (8) (10) 5 (11) 4 2 [1]

**6-2. PICTURE TUBE** ● : BVTP3×12 7-685-648-79

